



QUICK START GUIDE

Marine Vacuum Bags

620 × 1000 mm · PA/PE embossed film, 150 µm per side (300 µm total)

THE ONE THING TO GET RIGHT

Place the flat (**smooth**) side of the bag facing **DOWN** onto the sealing strip.



✓ **CORRECT**



Flat face lies continuously along the strip.

✗ **INCORRECT**



No continuous flat contact. Do not seal like this.

1

Inspect the bag

Check the film and factory seams for damage before use.

3

Clean the sealing area

Wipe the strip and bag mouth dry and free of debris.

5

Run the cycle

Follow the sealing unit's own operating instructions.

2

Load the waste

Leave clear film above the contents for the seal.

4

Lay it flat side down

Mouth square to the strip, film flat, no creases.

6

Check the seal

Inspect the full width of the seal line before removing.



WARNING

Do not vacuum pack glass, aerosols or pressurised containers. Do not overfill. A seal made over contamination or a crease can fail without warning.

STORAGE Keep bags in a cool, dry space, clear of sharp edges and direct sunlight.